



NOTES:

1. Locate air valve and stop valve behind sidewalk.
2. Minimum depth of cover to top of air valve body is 30".
3. Use elbow fittings where bending of 1-inch poly pipe is not possible due to water main depth.

AutoCAD: Waterline Air Valve

dwc 3-00
DRR

AIR VALVE

PAGE NO:

16